

ICOM IC-A4 Operating Guide

Beginning Operation

- 1) Rotate [VOL] to turn power on and adjust the audio level.
- 2) *To open the squelch:*
Push and hold [SQL] to open the squelch.
To close the squelch:
Release [SQL] to close the squelch.

Frequency Selection

- 1) Push [V/M] to select memory channel mode or VFO mode.
>MR appears when memory mode is selected.
- 2) Select the desired memory channel or frequency with the [^]/[v] keys.

Memory Programming

- 1) Push [V/M] to select VFO mode.
- 2) Push [^] or [v] to select the desired frequency.
- 3) Push [MW] for 5 sec. to enter memory programming mode.
>MR and memory channel number appears
- 4) Push [^] or [v] to select the desired memory channel number.
- 5) Push [MW] for 2 sec. to program the information into the current channel and return to the VFO mode.

Setting Lockout Channels

- 1) Push [V/M] to select memory mode, if necessary
>MR appears
- 2) Push [^] or [v] to select a memory channel to set as a lockout channel.
- 3) Push [SCAN] for 2 sec. to toggle the lockout setting ON/OFF.
>"SKIP" appears when the channel is set as a lockout channel.

Programming Memory Names

- 1) Select the memory channel to be programmed:
>Push [V/M] to select memory mode
>Push [^] or [v] to select the memory channel number.
- 2) Push [V/M] for 5 sec. to enter memory name writing mode.
- 3) Push [SCAN] or [SQL] several times to enter the desired name.
>To erase a character, overwrite with a "space".
>To move the cursor forwards or backwards, use [^] or [v].
>Push [key] for 2 sec. to erase all characters.
- 4) Push [MW] for 2 sec. to input the set name.
>Flashing stops.
>Memory channels can be programmed with names of up to 5 characters in length.
>When no name is programmed, the display shows the operating frequency.

Memory Scan

- 1) Push [V/M] to select memory mode if necessary.
- 2) Push [SCAN] to start scan.
>To change the scan direction, push [^] or [v].
- 3) Push [SCAN] again to stop scan.

VFO Scan

- 1) Push [V/M] to select VFO mode if necessary.
- 2) Push [SCAN] to start scan
>To change the scan direction, push [^] or [v].
- 3) Push [SCAN] again to stop scan.

Initial Set Mode

- 1) While pushing [V/M] + [key], rotate power ON.
- 2) Push [^] or [v] one or more times to select the desired display as follows.
>"mn": memory names.
>"bP": beep tone ON/OFF.
>"St": side tone ON/OFF.
- 3) Push [key] to select the desired condition.
- 4) Push [M/W] to exit initial set mode.

Resetting the CPU

While pushing [V/M] + [MW] + [SCAN], turn power ON to reset the transceiver.
>"CLEAR" appears briefly to indicate the CPU has been reset.

Caution: Resetting the CPU returns all programmed contents to their default settings.

Setting Squelch Level

While pushing [SQL], push [^]/[v] to adjust the squelch level.

Key Lock Function

Push [key] for 2 sec. to toggle the key lock function ON/OFF.

Dial Select Function

- 1) Push [V/M] to select VFO mode.
- 2) Push [V/M] for 2 sec. one or more times to select the desired tuning increment.
>1 MHz tuning, 100 KHz tuning or regular tuning steps can be selected
- 3) Push any key to return to normal operation